




ROTARY (R.E.B.) UNIONS



* Note: The components indicated by (*) rotate with the machine shaft.

Rotary (R.E.B.) Union - Type B.E.

- 1. Adaptor, s.g. iron
- 2. Bellows subassembly, brazed stainless steel / carbon
- 3. Gaskets
- 4. Body, s.g. iron
- 5. Seal ring, hardened stainless steel
- 6. Locking screws, h.t. steel
- 7. Locking ring inner
- 8. Ball bearings shielded from the seal chamber
- 9. Locking ring outer
- 10. Rotary spindle, steel

Description

The rotary R.E.B. union is a self-contained, self-supporting rotary seal for the leak-proof transfer of fluids such as steam, water, air and oil to and from rotating machine shafts. The type of rotary seal fitted to this model is a Filton® Bellows Seal containing a flexible stainless steel bellows which is self-adjusting, eliminating the maintenance common with conventional packed glands. Rotary sealing is created by relative rotation between extremely flat sealing faces (see item #2 and #5 in diagram above) held in contact by the spring characteristics of the bellows combined with an additional sealing force created by the pressure of the fluid passing through the rotary union. The bearings fitted to the union are standard ball bearings which are supplied with the initial lubrication completed prior to shipping. A shield is fitted to the seal chamber side of the ball bearings. There are three variations of the stationary adapter end:

1) Type B.E. - Single Flow


A single flow union suitable for transferring fluid in to or out of rotating machines.


2) Type S.T. - Double Flow (Stationary Center Tube)

Fitted with an adapter suitable for double flow with a stationary center tube. This gives flow areas through the center tube and annulus. The center tube - provided only if ordered - is fixed to the union end by means of a screw thread (dimension "O"). Flow can pass in through the center tube and return through the annulus or be reversed. For steam applications, the center tube is curved to reach the condensate in the bottom of the cylinder. If the roll neck diameter to length ratio prevents the use of a curved tube, a syphon elbow can be specified instead. See the Accessory Section or contact us for more information about the options available.


3) Type R.S. - Double Flow (Rotary Center Tube)

Fitted with an adapter suitable for a rotating center tube which must be located and driven by the machine. The center tube - provided only if ordered - rotates in a carbon bush. Flow can pass in through the center tube with the return through the annulus or be reversed. The center tube "sealing" system allows for a slight internal leakage between the supply and return lines. If these fluids must not mix, alternate designs are available. Please contact us for additional information.





Type S.T.



ROTARY (R.E.B.) UNIONS



Model and Dimensional Information

Nominal	Rotary (R.E.B.)	Union - Mode	Dimensions (mm unless specified otherwise)															
Size	B.E. (R or L)	S.T. (R or L)	R.S. (R or L)	A ⁽ⁱ⁾	B, N	c	D	Е	F	G, P	Н	ı	0	Q	S (ii)	Т	٧	w
40 (1-1/2")	18104	18105	18106	G. 1-1/2"	G. 1-1/2"	35	268	212	52	25	72	128	G. 3/4"	14	25.4, f8	50	64	108
50 (2")	17350	17238	17351	G. 2"	G. 2"	48	293	226	55	28	83	137	G. 1"	19	31.8, f8	60	76	127
65 (2-1/2")	18131	18132	18133	G. 2-1/2"	G. 2-1/2"	57	357	279	67	30	102	186	G. 1-1/4"	25	40, f8	55	90	150
80 (3")	17265	17266	17263	G. 3"	G. 3"	70	409	324	77	30	120	200	G. 1-1/2"	25	45, f8	70	110	180
90 (3-1/2")	17421	17422	17423	G. 3-1/2"	G. 4"	82	519	406	95	40	130	250	G. 2"	30	60, f8	60	140	240
100 (4")	17424	17425	17426	G. 4"	G. 4"	95	519	406	95	40	130	250	G. 2-1/2"	30	75, f8	60	140	240
125 (5")	17634.SF	17635.SF	17636.SF	Flanged (iii)	G. 5"	115	688	543	115	45	167	325	G. 3"	40	88, f8	70	192	290
150 (6")	17637.SF	17638.SF	17639.SF	Flanged (iii)	G. 6"	140	688	543	115	45	167	325	G. 3-1/2"	40	100, f8	70	192	290

⁽i) "G" is the designation for parallel pipe threads to BS.2779 and ISO 228/1.

Flow Capacity

Nominal	Rotary (R.E.B.)	Wate	er ^(iv)	Steam (v)	Air (vi)
Size	Union - Model	m³/h	l/min	kg/h	m³/h
40 (1 1/2")	B.E.	10.4	173	381	364
40 (1-1/2")	S.T. / R.S.	3.8	63	151	135
50 (2")	B.E.	19.5	325	717	684
30 (2)	S.T. / R.S.	6.3	105	357	215
65 (2-1/2")	B.E.	30.5	508	1120	1069
05 (2-1/2)	S.T. / R.S.	10.8	180	547	376
80 (3")	B.E.	41.6	693	1524	1455
80 (3)	S.T. / R.S.	14.9	248	807	511

Nominal	Rotary (R.E.B.)	Wate	er ^(iv)	Steam (v)	Air (vi)
Size	Union - Model	m³/h	l/min	kg/h	m³/h
00 /2 1/2"\	B.E.	57.0	950	2091	1996
90 (3-1/2")	S.T. / R.S.	23.4	390	942	818
100 (4")	B.E.	76.6	1277	2807	2679
	S.T. / R.S.	27.6	460	982	937
125 (5")	B.E.	112.2	1870	4859	4639
125 (5)	S.T. / R.S.	45.3	755	1617	1544
150 (6")	B.E.	166.3	2772	6997	6680
150 (6)	S.T. / R.S.	73.7	1228	2862	2760

⁽iv) Flow measured in cubic metres/hour at a velocity of 3 metres/second. (Also applies to other liquids.)

Maximum Operating Recommendations

Fluids: Water, steam, mineral oils and compressed air (lubricated). All fluids should be clean and free from abrasive particles.

* Note: It is not advisable to exceed or combine maximums.

Pressure: 17 bar maximum.

Vacuum: 740mm Hg. maximum (specify vacuum and we will test for this).

Temperature: -20°C to 180°C (with suitable effective lubrication up to 200°C)

-20°C to 120°C for sizes 125 (5") and 150 (6")

Speed: 600 r.p.m. maximum up to size 50 (2") 500 r.p.m. for 65 (2-1/2") and 80 (3")

400 r.p.m. for 90 (3-1/2") and 100 (4")

300 r.p.m. for 125 (5") and 150 (6")

Storage: Store indoors in a dry area between the temperature ranges of -10°C to 30°C.

Installation Procedures

1) A suitable run-in period before fitting is recommended. Rotate the R.E.B. at 100 r.p.m. for 30 minutes for sizes ranging from 40 (1-1/2") to 80 (3"), and at 50 r.p.m. for 1 hour for all other sizes above.

⁽ii) The tolerance "f8" is to BS.EN 20286-2 and ISO 286-2.

⁽iii) Please contact us for more information about flanged dimensions.

⁽v) Flow in kilograms/hour at a velocity of 30 metres/second and a pressure of 6 bar.


⁽vi) Flow in cubic metres/hour free air at a velocity of 15 metres/second and a pressure of 6 bar.




ROTARY (R.E.B.) UNIONS

Installation Procedures (Continued)

- 2) Add system liquid if seals squeak.
- 3) A torque arrestor should be fitted, but this must not restrict the rotary union.
- 4) Ensure that the spindle thread is RH or LH to suit the direction of rotation of the machine shaft.
- 5) If the machine shaft reverses direction of rotation, securely lock the spindle or (preferably) use a flanged connection.
- 6) DO NOT fix valves etc. directly on to the rotary union.



Part Identification



Nominal	1	2	3	4	- Adapte	er	5	6	7	8	9	10	11	12	13	14	15
Size	Retainer	C/T Bearing	Screw	B.E.	S.T.	R.S.	Seal Kit	Body	Screw	Screw	Locking Ring	Nilos Ring	Bearing Kit	Stud	Nut	Locking Ring	Spindle
40 (1-1/2")	18103/3	18103/2	M5 x 0.8	18103/1	18102/1	18101/1	S. 1151/3	18104/8	M6 x 1.0	M5 x 0.8	18104/4	18104/5	S. 1235/0	17238/4	M8 x 1.25	18104/2	18104/3
50 (2")	15473/1	15473/3	M5 x 0.8	15473/2	15472/1	15471/1	S. 1171/4	17238/11	M6 x 1.0	M4 x 0.7	17238/5	17238/12	S. 1235/1	17238/4	M8 x 1.25	17238/7	17238/8
65 (2-1/2")	15476/3	18133/2	M6 x 1.0	18133/1	18132/1	18131/1	S. 1171/8	18131/15	M6 x 1.0	M5 x 0.8	18131/10	18131/11	S. 1235/5	18131/6	M10 x 1.5	18131/13	18131/14
80 (3")	15479/3	15479/2	M6 x 1.0	15479/1	15478/1	15477/1	S. 1171/5	17263/11	M6 x 1.0	M5 x 0.8	17263/5	17263/16	S. 1235/2	17423/1	M12 x 1.75	17263/7	17263/8
90 (3-1/2")	16173/3	16173/2	M6 x 1.0	16173/1	16172/1	16171/1	S. 1151/6	17423/7	M5 x 0.8	M5 x 0.8	17423/2	17155/15	S. 1235/3	17423/1	M12 x 1.75	17423/8	17423/9
100 (4")	16176/3	16176/2	M6 x 1.0	16176/1	16175/1	16174/1	S. 1151/6	17423/7	M5 x 0.8	M5 x 0.8	17423/2	17155/15	S. 1235/3	17423/1	M12 x 1.75	17423/8	17426/1
125 (5")	15488/3	15488/2	M8 x 1.25	15488/1	15487/1	15486/1	S. 1151/7	17635/3	M12 x 1.75	M12 x 7.5	17635/5	17635/4	S. 1235/4	17635/7	M16 x 2	17635/2	17635/1
150 (6")	16702/1	16702/3	M8 x 1.25	16702/1	16703/2	16704/1	S. 1151/7	17635/3	M12 x 1.75	M12 x 7.5	17635/5	17635/4	S. 1235/4	17635/7	M16 x 2	17635/2	17637/1

ROTARY (R.E.B.) UNIONS



Maintenance and Overhaul

- 1) Remove nuts (13) and washers which allows for the removal of adaptor (4).
- 2) Remove bellows subassembly and gasket of seal kit (5).
- 3) Remove locking screw (7) and unscrew locking ring (14 RH Thread) and extract spindle (15) complete with ball bearings, etc.
- 4) Remove locking screws from the rubbing ring of seal kit (5), unscrew the rubbing ring (RH or LH thread) and remove gasket.
- 5) Thoroughly clean the ball bearing kit (11), check the condition of the bearings and re-grease. If there is any doubt about the condition, replace the bearing kit and pre-pack with an approved grease.
- 6) To replace the bearing kit (11), remove locking screws (8), bearing locking ring (9 RH or LH Thread) and Nilos ring (10). Press off the bearing kit.
- 7) If the adaptor (4) is Type R.S., remove locking screw (3), unscrew locking ring (1 RH Thread) and remove C/T bearing (2).
- 8) Replace seal kit (5), bearing kit (11) and if type RS, C/T bearing (2). Handle seal kits with care to avoid damaging the precision lapped seal faces.
- 9) Thoroughly clean all parts before reassembly (which is virtually the reverse of the above steps).
- 10) After reassembly, follow the recommended installation procedures and allow for a suitable run-in period to ensure the seals are working correctly before refitting to the machine.

Minimum	Length	for
Flexible	Hose	

M.240/7 M.240/8 M.240/9
M.240/9
M.240/10
M.240/10
M.240/11
M.240/12
M.240/13

* Note: For the 125 (5") and 150 (6") models, there is a screwed adjusting ring on the flanged end of the body which is locked with a screw and can be adjusted to give 6mm compression on the bellows subassembly if necessary.

Lubrication

The bellows seal fitted to the rotary R.E.B. union is self-adjusting within its working life. The ball bearings are lubricated prior to shipping with a Bentone-base grease and occasionally require re-lubrication with a compatible grease; generally once per shift on "hot" applications and once per month on "cold" applications. For more specific recommendations, contact the grease manufacturer. Recommended lubricants include:

ACHESON COLLOIDS C Multilube Bearing Grease Hi-Temp Bearing Grease		DOW CORNING Molykote 44M	-40°C / +180°C	ROCOL LTD. Sapphire BG.442
BARDAHL Multipurpose Grease #2 Haute Temperature	-20°C / +160°C -10°C / +180°C	ELF OIL Multi 2 HTB 3	-25°C / +130°C -25°C / +180°C	SHELL Alvania RA Darina Grease R2
BP Energrease LS2 Energrease HTB2	-30°C / +130°C -20°C / +180°C	ESSO Beacon 2 IL 2880	-25°C / +125°C -20°C / +180°C	TEXACO Multifak AFB2 Starfak Ultratemp 2
BURMAH-CASTROL Spheerol AP3 Spheerol BNS	-30°C / +110°C -25°C / +180°C	MOBIL Mobilplex 47 Mobiltemp 1	-25°C / +150°C +10°C / +180°C	* Note: For subz please co
CALTEX (UK) LTD. Regal Starfak Premium 2 RPM Ind. Grease Heavy Thermatex EP	-40°C / +120°C -25°C / +165°C -20°C / +180°C	PETROFINA (UK) LTD. Marson L2 Bentex A3	-20°C / +120°C -20°C / +190°C	for the cor

Note: For subzero temperatures, please contact Nuraseal to ensure the model is suitable for the conditions.

-30°C / +150°C -40°C / +180°C

-40°C / +145°C +10°C / +190°C

-40°C / +120°C

-40°C / +175°C



SALES AND SERVICE

For nearly three decades, Nuraseal has been providing sales and service for all Filton[®] Rotary Union Products. Whether you require new or custom unions, replacement components, technical support or assistance with maintenance inquiries, Nuraseal will be able to help you solve your application requirements throughout North America and abroad. Contact us to find out how we can help you today!

Need Help? Here's what to do before you call. . . 1-888-NURASEAL (687-2732)

Toll Free! 1-888-NURASEAL (687-2732)

In order to better serve your needs, it is helpful to collect some basic information prior to contacting us. Most of this information will be located on a plate fastened to the unit itself or easily identified by visual inspection.

- Rotary Union Model type i.e. Rotary R.E. Union
- Part number i.e. 16663.
- Serial number generally identified either by a combination of two letters followed by four numbers or four numbers followed by a single letter i.e. ZN5631
- Nominal size
- Direction of rotation if there is a groove in the spindle, it is a left-hand thread.

Other information that is helpful, especially when trying to select a suitable model or when troubleshooting during times of maintenance or unit failure, include:

- · Type of fluid, flow rate, pressure, temperature
- Ambient temperature
- Rotational speed
- Working cycle
- Any unusual conditions i.e. exposure to harsh environments, etc.

Quick Selection and Reference Guide

Check the Application Requirement column below for the appropriate fluid and size range. Turn to the page for the model indicated and check the full working conditions and limitations. If more than one model is indicated, examine the application information on the appropriate pages. Contact us for more information.

		А	pplication F	Requirments				Rotary Union	Available
Air	Gas ⁽³⁾	Oil (Lubricating)	Oil (Hydraulic)	Oil (Heat Transfer)	Steam	Vacuum	Water	Model Type	Size Range ⁽¹⁾
Y (2)	Υ	Υ		Υ	Υ	Υ	Υ	R.E.	8 (1/4") - 32 (1 1/4")
Y (2)	Υ	Υ				Υ	Υ	P.B.	15 (1/2") - 25 (1")
Y (2)	Υ	Υ		Υ	Υ	Υ	Υ	R.E.B.	40 (1 1/2") - 150 (6") ⁽⁵⁾
				Y (4)	Υ		Υ	C.B.	8 (1/4") - 32 (1 1/4")
				Y ⁽⁴⁾	Υ		Υ	C.B.N.	40 (1 1/2") - 150 (6") ⁽⁵⁾
Y (2)		Υ					Υ	L.C.	8 (1/4") - 20 (3/4")
Υ						Υ		P.N.	8 (1/4") - 20 (3/4")
Y (2)	Υ	Υ	Υ			Υ		M.C.T.	8 (1/4") - 25 (1")
Y 2)		Υ	Υ			Υ	Υ	I.N.T.	8 (1/4") - 25 (1")

Legend:

- (Y) Suitable for your application, but check the working condition information
- (1) Size range as measured at the rotary spindle connection end
- (2) Lubricated air only (if air is dry and P.N. model is unsuitable, special seals are available)
- (3) Depends on type of gas and working conditions
- (4) Flanges may be required depending on the working conditions
- (5) Flanges may be fitted to assist for removal and maintenance on sizes 100 (4") and larger.



